



Generate Report: [Select A Report](#) · View Form: [Select A Form](#)

Sample Details

Sample Name: N243-2-03-N

Building:	<input type="text" value="N243"/>	Floor:	<input type="text" value="2"/>	Location:	<input type="text" value="C207"/>
Canister ID:	<input type="text" value="AC01223"/>	Flow Controller ID:	<input type="text" value="FCA00373"/>		
Interval:	<input type="text" value="24"/>	Sample Type:	<input type="text" value="Work Area"/>	HVAC On:	<input type="text" value="True"/>

Canister Setup By:	<input type="text" value="DA"/>	Date Time:	<input type="text" value="5/24/2012 6:12:21 AM"/>	Initial Reading:	<input type="text" value="-29.9"/> Hg Inches
--------------------	---------------------------------	------------	---	------------------	--

Sample Started By:	<input type="text" value="BW"/>	Date Time:	<input type="text" value="5/24/2012 1:00:00 PM"/>	Vacuum Reading:	<input type="text" value="-28.5"/> Hg Inches
--------------------	---------------------------------	------------	---	-----------------	--

Start Comments:



Sample Ended By:

BW

Date Time:

5/25/2012 1:34:33 PM

Vacuum Reading:

-7

Hg Inches

End Comments:

QA'd:

QA'd By:

HTY