



Generate Report: [Select A Report](#) · View Form: [Select A Form](#)

## Sample Details

Sample Name: N243-3-01-N

Building:	<input type="text" value="N243"/>	Floor:	<input type="text" value="3"/>	Location:	<input type="text" value="N310"/>
Canister ID:	<input type="text" value="AC00575"/>	Flow Controller ID:	<input type="text" value="FCA00356"/>		
Interval:	<input type="text" value="24"/>	Sample Type:	<input type="text" value="Pathway"/>	HVAC On:	<input type="text" value="True"/>

Canister Setup By:	<input type="text" value="DA"/>	Date Time:	<input type="text" value="5/24/2012 6:22:32 AM"/>	Initial Reading:	<input type="text" value="-29.9"/> Hg Inches
--------------------	---------------------------------	------------	---	------------------	--

Sample Started By:	<input type="text" value="MW"/>	Date Time:	<input type="text" value="5/24/2012 2:53:40 PM"/>	Vacuum Reading:	<input type="text" value="-30"/> Hg Inches
--------------------	---------------------------------	------------	---	-----------------	--

Start Comments:



Sample Ended By:  Date Time:  Vacuum Reading:  Hg Inches

End Comments:

QA'd:  QA'd By: