



Generate Report: [Select A Report](#) · View Form: [Select A Form](#) ·

Sample Details

Sample Name: N243-B-02-F

Building:	<input type="text" value="N243"/>	Floor:	<input type="text" value="Basement"/>	Location:	<input type="text" value="C002"/>
Canister ID:	<input type="text" value="AC00794"/>	Flow Controller ID:	<input type="text" value="FCS00012"/>		
Interval:	<input type="text" value="24"/>	Sample Type:	<input type="text" value="Work Area"/>	HVAC On:	<input type="text" value="False"/>

Canister Setup By:	<input type="text" value="LC"/>	Date Time:	<input type="text" value="5/27/2012 8:38:18 AM"/>	Initial Reading:	<input type="text" value="-30.2"/> Hg Inches
--------------------	---------------------------------	------------	---------------------------------------------------	------------------	----------------------------------------------

Sample Started By:	<input type="text" value="BW"/>	Date Time:	<input type="text" value="5/27/2012 2:51:26 PM"/>	Vacuum Reading:	<input type="text" value="-29.5"/> Hg Inches
Start Comments:	<input type="text"/>				



Sample Ended By: Date Time: Vacuum Reading: Hg Inches

End Comments:

QA'd: QA'd By: