



Generate Report: [Select A Report](#) View Form: [Select A Form](#)

Sample Details

Sample Name: N243-B-02-N

Building:	<input type="text" value="N243"/>	Floor:	<input type="text" value="Basement"/>	Location:	<input type="text" value="C002"/>
Canister ID:	<input type="text" value="AC00440"/>	Flow Controller ID:	<input type="text" value="FCA00375"/>		
Interval:	<input type="text" value="24"/>	Sample Type:	<input type="text" value="Work Area"/>	HVAC On:	<input type="text" value="True"/>

Canister Setup By:	<input type="text" value="DA"/>	Date Time:	<input type="text" value="5/24/2012 6:13:31 AM"/>	Initial Reading:	<input type="text" value="-30"/> Hg Inches
--------------------	---------------------------------	------------	---	------------------	--

Sample Started By:	<input type="text" value="BW"/>	Date Time:	<input type="text" value="5/24/2012 1:20:07 PM"/>	Vacuum Reading:	<input type="text" value="-30"/> Hg Inches
--------------------	---------------------------------	------------	---	-----------------	--

Start Comments:



Sample Ended By:	<input type="text" value="BW"/>	Date Time:	<input type="text" value="5/25/2012 1:20:51 PM"/>	Vacuum Reading:	<input type="text" value="-9"/> Hg Inches
------------------	---------------------------------	------------	---	-----------------	---

End Comments:

QA'd: QA'd By: