



Generate Report: [Select A Report](#) · View Form: [Select A Form](#)

Sample Details

Sample Name: N243-B-04-F

Building:	<input type="text" value="N243"/>	Floor:	<input type="text" value="Basement"/>	Location:	<input type="text" value="C008"/>
Canister ID:	<input type="text" value="AC00679"/>	Flow Controller ID:	<input type="text" value="FCA00626"/>		
Interval:	<input type="text" value="24"/>	Sample Type:	<input type="text" value="Work Area"/>	HVAC On:	<input type="text" value="False"/>

Canister Setup By:	<input type="text" value="DA"/>	Date Time:	<input type="text" value="5/27/2012 11:32:38 AM"/>	Initial Reading:	<input type="text" value="-30.1"/> Hg Inches
--------------------	---------------------------------	------------	--	------------------	--

Sample Started By:	<input type="text" value="HY"/>	Date Time:	<input type="text" value="5/27/2012 2:45:30 PM"/>	Vacuum Reading:	<input type="text" value="-28.5"/> Hg Inches
--------------------	---------------------------------	------------	---	-----------------	--

Start Comments:



Sample Ended By: Date Time: Vacuum Reading: Hg Inches

End Comments:

QA'd: QA'd By: