



Generate Report: [Select A Report](#) · View Form: [Select A Form](#)

Sample Details

Sample Name: N243-B-04-N

Building:	<input type="text" value="N243"/>	Floor:	<input type="text" value="Basement"/>	Location:	<input type="text" value="C008"/>
Canister ID:	<input type="text" value="AC00612"/>	Flow Controller ID:	<input type="text" value="FCA00488"/>		
Interval:	<input type="text" value="24"/>	Sample Type:	<input type="text" value="Work Area"/>	HVAC On:	<input type="text" value="True"/>

Canister Setup By:	<input type="text" value="DA"/>	Date Time:	<input type="text" value="5/24/2012 6:14:39 AM"/>	Initial Reading:	<input type="text" value="-30"/> Hg Inches
--------------------	---------------------------------	------------	---	------------------	--

Sample Started By:	<input type="text" value="MW"/>	Date Time:	<input type="text" value="5/24/2012 12:15:31 PM"/>	Vacuum Reading:	<input type="text" value="-29"/> Hg Inches
Start Comments:	<input type="text"/>				



Sample Ended By: Date Time: Vacuum Reading: Hg Inches

End Comments:

QA'd: QA'd By: