



Generate Report: [Select A Report](#) · View Form: [Select A Form](#) ·

## Sample Details

Sample Name: N243-B-06-F

Building:	<input type="text" value="N243"/>	Floor:	<input type="text" value="Basement"/>	Location:	<input type="text" value="050"/>
Canister ID:	<input type="text" value="AC01893"/>	Flow Controller ID:	<input type="text" value="FCA00515"/>		
Interval:	<input type="text" value="24"/>	Sample Type:	<input type="text" value="Work Area"/>	HVAC On:	<input type="text" value="False"/>

Canister Setup By:	<input type="text" value="DA"/>	Date Time:	<input type="text" value="5/27/2012 9:05:15 AM"/>	Initial Reading:	<input type="text" value="-30.1"/> Hg Inches
--------------------	---------------------------------	------------	---	------------------	--

Sample Started By:	<input type="text" value="LC"/>	Date Time:	<input type="text" value="5/27/2012 3:15:52 PM"/>	Vacuum Reading:	<input type="text" value="-29"/> Hg Inches
Start Comments:	<input type="text"/>				



Sample Ended By:

HY

Date Time:

5/28/2012 3:11:17 PM

Vacuum Reading:

-4.5 Hg Inches

End Comments:

QA'd:

QA'd By:

HTY