



Generate Report: [Select A Report](#) · View Form: [Select A Form](#)

Sample Details

Sample Name: N243-B-08-F

Building:	<input type="text" value="N243"/>	Floor:	<input type="text" value="Basement"/>	Location:	<input type="text" value="C010"/>
Canister ID:	<input type="text" value="AC01628"/>	Flow Controller ID:	<input type="text" value="FCA00546"/>		
Interval:	<input type="text" value="24"/>	Sample Type:	<input type="text" value="Pathway"/>	HVAC On:	<input type="text" value="False"/>

Canister Setup By:	<input type="text" value="DA"/>	Date Time:	<input type="text" value="5/27/2012 11:40:01 AM"/>	Initial Reading:	<input type="text" value="-30.1"/> Hg Inches
--------------------	---------------------------------	------------	--	------------------	--

Sample Started By:	<input type="text" value="HY"/>	Date Time:	<input type="text" value="5/27/2012 2:42:42 PM"/>	Vacuum Reading:	<input type="text" value="-29"/> Hg Inches
Start Comments:	<input type="text"/>				



Sample Ended By: Date Time: Vacuum Reading: Hg Inches

End Comments:

QA'd: QA'd By: