



Generate Report: [Select A Report](#) · View Form: [Select A Form](#)

Sample Details

Sample Name: N243-B-08-N

Building:	<input type="text" value="N243"/>	Floor:	<input type="text" value="Basement"/>	Location:	<input type="text" value="C010"/>
Canister ID:	<input type="text" value="AC00142"/>	Flow Controller ID:	<input type="text" value="FCA00399"/>		
Interval:	<input type="text" value="24"/>	Sample Type:	<input type="text" value="Pathway"/>	HVAC On:	<input type="text" value="True"/>

Canister Setup By:	<input type="text" value="DA"/>	Date Time:	<input type="text" value="5/24/2012 5:55:56 AM"/>	Initial Reading:	<input type="text" value="-29.8"/> Hg Inches
--------------------	---------------------------------	------------	---	------------------	--

Sample Started By:	<input type="text" value="MW"/>	Date Time:	<input type="text" value="5/24/2012 3:01:20 PM"/>	Vacuum Reading:	<input type="text" value="-28"/> Hg Inches
--------------------	---------------------------------	------------	---	-----------------	--

Start Comments:



Sample Ended By: Date Time: Vacuum Reading: Hg Inches

End Comments:

QA'd: QA'd By: